



UKH07A

INSTRUCTION MANUAL

Please keep this manual and the product code number for future reference and to order replacement parts if necessary

GENERAL INSTRUCTIONS

- Please read this manual carefully and thoroughly before proceeding.
- For your safety, it is recommended that you wear safety glasses at all times during installation.

INSTALLATION OVER CERAMIC TILES

- If you are installing the shower door over ceramic tiles, make sure that the tiles lay completely under the wall jamb.
- Use mildew resistant silicone to seal the gaps where the ceramic tiles meet the fixed panel.

NOTICE

- Caulking is not required inside the shower, unless otherwise stated.
- Some models are equipped with clear sealing gaskets.



CARE FOR YOUR SHOWER DOOR

- Do not use scouring powder pads or sharp instruments on metal pieces or glass panels.
- To keep the panels and metal parts looking new, occasionally wipe them down with a mild soap diluted in water.
- We recommend wiping the glass panels with a squeegee after each use.

CAUTION

- The most fragile parts of tempered glass panels are the corners. Therefore, it is critical you have the rubber blocks in place so the glass never touches the tile surface you are installing onto. Please make sure the glass is always on cardboard packaging or rubber blocks while out of the packaging prior/during install. Rubber block is provided in your hardware pack however you can use wood, cardboard or other rubber products to protect against breakage.

TOOLS REQUIRED


 SPIRIT LEVEL	 TAPE MEASURE	 POWER DRILL	 DRILL BITS	 SILICONE
 SCREW DRIVER	 PENCIL	 X-ACTO KNIFE	 MALLET	 SAFETY GLASSES



2 PEOPLE REQUIRED


Product specifications are subject to change without notice.

UKH07(A+B3)



*Our products are available in a variety of colors and sizes to suit your needs.

PARTS LIST




ITEM	PARTS	DIAGRAM	QTY
1	Door panel		1
2	Wall mount hinges		2
3	Plastic seal		1
4	Plastic seal		1

ITEM	PARTS	DIAGRAM	QTY
5	Plastic seal		1
6	Plastic seal		1
7	Handle		1

UKH07A PART LIST

PARTS OVERVIEW



PLASTIC HORSESHOE SHIM USAGE INSTRUCTIONS

- 1
- HS44
1/2"x4"
Plastic Horseshoe Shims
2 Pcs/Bag



- 2
- PLACE
Slide the horseshoe shim
under the glass at the
location where support
is needed.



- 3
- ADJUST
Move the shim toward or
away from the glass edge
to fine-tune the position.



- 4
- STACK (IF NEEDED)
Use multiple shims together
to achieve the required height.



INSTALLATION NOTES

- Ensure the floor is clean and level before installation.
- Use the clear plastic setting blocks to level and support the glass as needed.
- Shims are used to space and align the panels at the bottom.



QUALITY & RELIABILITY

- High-quality components
- for a secure and
- long-lasting installation


Shower Door Installation

The product can be installed in either left-hand or right-hand configuration.



STEP 1


Preparation



Carefully inspect the condition of the walls before installation. Ensure that both wall surfaces are even, plumb, and smooth.

STEP 2

Measure the Door Opening




Measure the opening width at the top, middle, and bottom. All three measurements should be consistent. Differences between the measurements indicate the walls may be out of plumb, and the shower door may not install properly. The opening width must be at least $\frac{3}{8}$ " wider than the door panel and no more than 1" wider than the door panel.

Example: A 26" door panel requires an opening width between $26 \frac{3}{8}$ " and 27".


STEP 3

Install the Hinges


Outside



Inside



Attach the hinges to the door panel. Ensure the smooth, flat face of each hinge is positioned on the outside of the glass door.




Caution

Never place the glass directly on tile, concrete, or any hard surface. Always support the glass on wood, cardboard, or another protective material. In order to help protect the glass edges and corners from damage, leave the corner protectors in place until the installation process is complete.

STEP 4




Position the Door Panel



Place two 1/2" thick shims on the threshold or shower base. Carefully place the glass door onto the shims. Position the hinged side of the door against the wall and check that the door is perfectly plumb using a level.

STEP 5


Mark the Hinge Locations



Hold the door panel in position and mark the drilling locations for both hinges on the wall.

STEP 6




Drill Holes And Install Wall Anchors



Carefully remove the door panel and place it on a protective mat or cardboard. Using a 1/4" drill bit, drill the marked holes and install the wall anchors. Trim any excess portion of the wall anchors that extends beyond the wall surface using a utility knife, ensuring the hinges sit flush against the wall.

STEP 7



Install the Door Panel



Place the glass door back onto the shims. Secure both hinges to the wall using the provided screws. Make sure the hinge surface with screw holes is positioned on the inside of the shower enclosure.

STEP 8


Install the Door Handle



Disassemble the door handle and install it onto the door panel. The side of the handle with screw holes should be installed on the inside of the shower enclosure, with the screw holes facing downward. Tighten all handle components securely to ensure the handle is firmly attached to the glass.

STEP 9

Install Door Panel Plastic Seals




Measure the required length for each plastic seal and use a utility knife to trim the seals to size. Then attach the plastic


Note:
Plastic seal (No. 3) should be cut into three pieces to attach to glass around the hinges.

STEP 10


Install L Angle Jamb Seal (Optional)




Use a level to mark a vertical line on the wall, ensuring the line aligns with the edge of the door panel when it is in the closed position. Attach the L-angle jamb seal to the wall along the marked line.



Door Swings Outward
using L-Angle Jamb
Seal



Door Swings Inward
using L-Angle Jamb
Seal



Door Swings Inward &
Outward using Bulb
Seal



Combine the L-Angle
Jamb Seal and Bulb
Seal to fill the larger
gap between the door
panel and the wall

Use the included L-angle jamb seal and bulb seal to control the door swing direction and to fill both smaller and larger gaps between door panel and wall.

UNIKOO LIMITED WARRANTY

This warranty applies to Unikoo Glass & Hardware products purchased after January 1, 2020.

Unikoo offers the following parts only, limited warranty (for the designated period) for its products and components thereof. Unikoo's limited warranty extends only to the original owner/end-user, is for household use only (for commercial use please see COMMERCIAL USE section), and is not transferable to a subsequent owner. Unikoo reserves the right to modify this limited warranty at any time, it being understood that such modifications will not alter the limited warranty conditions applicable at the time of sale of the products in question.

This limited warranty extends for the designated period of time so long as the product remains in use in its original place of installation. This limited warranty applies only to Unikoo® products purchased from an authorized dealer in the United States or Canada. Proof of purchase (original sales receipt) from the original consumer purchase must be provided with all warranty claims.

IN NO EVENT SHALL THE LIABILITY OF UNIKOO EXCEED THE PURCHASE PRICE OF THE PRODUCT. NO RESPONSIBILITY IS ASSUMED BY UNIKOO FOR ANY SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES.

Unikoo recommends that its products be installed by a professional with experience in the installation of bathroom (specifically shower and tub doors) products. Installation of certain products, including, without limitation, glass products (i.e., shower and tub doors) by an inexperienced installer may result in glass breakage and, consequently, may cause personal injury or even death. Installation must be in accordance with the installation manual without modification. Any deviation from the installation manual shall VOID THE WARRANTY.

PARTS ONLY LIMITED WARRANTY

The limited warranty covers replacement parts for all defects for the designated period. LABOR CHARGES AND/OR DAMAGE INCURRED DURING INSTALLATION, REPAIR, OR REPLACEMENT, AS WELL AS ANY OTHER KINDS OF ANCILLARY COST, LOSS OR DAMAGE ARE EXCLUDED. Please allow 24-48 hours for processing of warranty issued parts. Once warranty replacement parts are shipped, the warranty is activated, and the product cannot be returned for refund thereafter.

COMMERCIAL USE

Notwithstanding any other terms in this warranty, the duration of the applicable limited warranty excludes all industrial, commercial and business usage. THE WARRANTY PERIOD FOR PRODUCTS INSTALLED FOR COMMERCIAL APPLICATIONS OR USED IN COMMERCIAL VENTURES, INCLUDING BUT NOT LIMITED TO MOTELS, HOTELS, CASINOS, STUDENT HOUSING, CONDOS, APARTMENTS, AND FITNESS CENTERS, IS A ONE (1) YEAR LIMITED WARRANTY FROM THE DATE OF PURCHASE FOR SHOWER DOORS, BATHTUB DOORS, SHOWER ENCLOSURES, SHOWER BASES, AND BACKWALLS, WITH ALL OTHER TERMS OF THIS WARRANTY APPLYING EXCEPT THE DURATION OF THE WARRANTY.

OTHER EXCLUSIONS

UNIKOO HEREBY DISCLAIMS ALL WARRANTIES, EXPRESS OR IMPLIED, FOR PRODUCTS SOLD AS DEALER OR STORE DISPLAYS, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

LIMITED WARRANTY TERMS

Unikoo will, at its election, repair or replace a product found by Unikoo, in its sole judgment, to be defective within the warranty period under normal residential use and maintenance. The replacement of a product is limited to supplying a replacement product or part (same as existing or if not available, comparable product). Unikoo's warranty obligation shall be discharged upon tender of parts, replacement, or repair of the product. Purchaser's refusal to accept the

tender terminates all warranty obligations and **VOIDS THE WARRANTY**. Cost of freight for returning products to Unikoo for repairs or replacement under this limited warranty is the responsibility of the customer. Cost of freight associated with shipping of replacement product(s) or parts covered by this limited warranty is the responsibility of the customer. Any product replaced or repaired during the warranty period will be covered only for the remaining period of the original limited warranty. In no event will Unikoo be liable for costs of repair or replacement of any installation material, including but not limited to tile, marble, etc. **UNIKOO IS NOT RESPONSIBLE FOR INSTALLATION, REMOVAL OR REINSTALLATION COSTS OF ANY PRODUCT REQUIRING WARRANTY SERVICES.**

Any modification or alteration of any Unikoo product will void the warranty. Neither the authorized Unikoo dealer, nor any other person, is permitted to make any affirmation, representation, or warranty other than those contained in this limited warranty. Any affirmation, representation, or warranty other than those contained in this limited warranty shall not be enforceable against Unikoo or any other person.

Unikoo recommends that product installations and repairs be performed by an experienced professional in accordance with the installation manual without modification. Installation or repairs that deviate from the installation manual shall **VOID THE WARRANTY**. This limited warranty shall not apply to breakage or damages caused by normal wear and tear, fault, carelessness, abuse, misuse, misapplication, improper maintenance, alteration or modification of the unit, as well as chemical or natural corrosion, accident, fire, flood, act of God or any other casualty. Improper care and cleaning will **VOID THE WARRANTY**. Use of cleaners containing abrasive cleansers, ammonia, bleach, acids, waxes, alcohol, solvents or other products not recommended for hardware finishes, glass or acrylic, as they may damage the metal or glass finish of your product, will **VOID THE WARRANTY**. For additional product maintenance instructions, please refer to the product installation manual. Unikoo is not responsible for any issues arising in connection with errors or omissions in information provided on Unikoo or dealers' websites. This limited warranty does not extend to any non-Unikoo plumbing or components installed by installers, end users or by any party other than Unikoo.

THE FOREGOING LIMITED WARRANTIES ARE IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. UNIKOO DISCLAIMS ALL LIABILITY FOR SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES. UNIKOO IS NOT LIABLE FOR PERSONAL INJURIES OR DEATH TO ANY PERSON OR FOR ANY INDIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES, LOSS OF USE, LOSS OF TIME, LOSS OF PROFITS, INCONVENIENCE, INCIDENTAL EXPENSES, LABOR OR MATERIAL CHARGES, OR ANY OTHER COSTS RESULTING FROM THE USE OF ITS PRODUCTS OR PERTAINING TO THE APPLICATION OF THE PRESENT WARRANTY OR RESULTING FROM THE REMOVAL OR REPLACEMENT OF ANY PRODUCT OR PART COVERED BY THIS WARRANTY.

PRODUCT WARRANTY PERIODS

The laws and regulations that govern the installation and use of shower or tub doors, shower enclosures, and other accessories vary widely by region, state or municipality. Except as otherwise provided above, Unikoo makes no warranties, express or implied, including warranties of merchantability and fitness for a particular purpose, or compliance with any code. Unikoo is not responsible for verifying building code restrictions on installation or use, and any such compliance is excluded from this warranty. Unikoo reserves the right to modify this limited warranty at any time - such warranty modifications will not alter the warranty applicable at the time of sale of the products in question. The warranty periods for specific products for consumer (non-industrial, non-commercial, non-business use only) are as specified below:

3 Years Limited Warranty – SHOWER DOOR HARDWARE, TUB DOOR HARDWARE, AND SHOWER ENCLOSURE HARDWARE

The Unikoo 3 Years Limited Warranty covers all shower door, tub door, and shower enclosure hardware, with the exception of glass. Unikoo warrants shower door, tub door and shower enclosure hardware (i.e. handles, rollers, hinges, profiles, clips, guides, brackets, towel bars) in chrome and brushed nickel finishes only to be free from defects in workmanship and materials under normal residential use for a period commencing from the initial date of purchase by the owner/ end-user, contractor or builder from an authorized Unikoo dealer for the life of the product as long as the original consumer purchaser resides in the home in which the product is installed. THE WARRANTY PERIOD FOR ANY COATING ON HARDWARE IN SATIN BRASS, SPACE GRAY OR MATTE BLACK FINISH SHALL BE LIMITED TO ONE (1) YEAR. THE WARRANTY PERIOD FOR PLASTIC SEAL STRIPS, SWEEPS OR ANY OTHER VINYL COMPONENTS SHALL BE LIMITED TO ONE (1) YEAR. UNIKOO DOES NOT WARRANT GLASS FOR SCRATCHES, CHIPS, WATER SPOTS, BREAKING OR ANY OTHER DAMAGE DURING OR AFTER INSTALLATION.

One (1) Year Limited Warranty - FAUCETS, ACCESSORIES AND SHOWER HEADS

Unikoo shower accessories are backed by a One (1) Year Limited Warranty. Unikoo warrants shower columns purchased by the owner/end-user, contractor or builder from an authorized Unikoo dealer to be free from defects in workmanship and materials under normal residential use for a period of one (1) year from the date of purchase of the product as long as the original consumer purchaser resides in the home in which the product is installed.

One (1) Year Limited Warranty – COMMERCIAL HARDWARE AND RAILING SYSTEMS

The Unikoo One (1) Year Limited Warranty covers all commercial hardware and railing system, with the exception of glass. All warranty claims are subject to inspection by UNIKOO before providing a resolution against the warranty claim. This warranty is void if it is determined after UNIKOO inspection that the Hardware has been improperly installed and/or maintained in a manner not conforming to UNIKOO guidelines and instructions provided at time of purchase. UNIKOO's responsibility to provide a resolution under said warranty will be limited to a refund of purchased price or provide a replacement for the hardware. The refund or replacement will constitute UNIKOO's limited liability and obligation for any and all defective material/workmanship for said warranty claim.

STATE LAWS AND THIS WARRANTY

Some states/provinces do not allow limitations on how long an implied warranty lasts, or the exclusion or limitation of special, incidental or consequential damages, so these limitations and exclusions may not apply to you. This warranty gives you specific legal rights. You may also have other rights, which vary from state to state or province to province.

WARRANTY SERVICE

To file a warranty claim, the following information is required:

- Name, address and telephone number
- Product model number, color, finish
- Complete description of problem (please note that additional information such as photos may be required to fully process your warranty claim)
- Date of purchase and from whom the product was purchased
- Proof of purchase (sales receipt, invoice, etc.)
- PO, Invoice or original purchaser name

Submit required information by email or mail:

Email: info@unikooogroup.com

Mailing Address: Unikoo Warranty Service Center

1820 S Santa Fe St, Santa Ana, CA 92705

or contact Technical Support at 888-404-5533 Monday - Friday 7:00 am - 4:00 pm PST

OTHER MODELS

